


CMH Airport Operational Flow

Runway Use – West Flow



Runway Use – East Flow

